

BC-4000 Industrial Metal Cleaner

BC 4000

DESCRIPTION

BC 4000 is a general purpose liquid alkaline cleaner intended to serve a variety of applications in general metal working and industrial applications.

KEY FEATURES

- **Good Cleaning** - effectively removes the soils normally found in metal working operations.
- **Safe on All Typical Industrial Metals** - to permit use throughout the shop.
- **Liquid Form** - for ease of handling, measuring and mixing.
- **Highly Concentrated** - for economical use. Available in quarts, gallons, 5 gallons, 55 gallon drums.
- **100% Bioderadable**

GENERAL PURPOSE

1. Parts cleaning to eliminate the need for individual products. Spray wash, agitated soak tank units, or wipe clean.
2. Floor cleaning.
3. Steam cleaning for general maintenance.
4. Central system cleaning.
5. Machine tool cleaning - Sumps and exteriors where water soluble or synthetic coolants are used.

HOW TO USE

Parts Cleaning:

1. **Spray Wash** - 10% concentration
2. **Agitated Soak Tank** - 5 to 10% concentration
3. **Wipe Application** - 10% concentration; Wet rag with mixture; Change/rinse rags often; Gloves recommended.

Floor Cleaning:

4. **Mop and Bucket** - 5 to 10% concentration
5. **Floor Scrubber** - 1 to 2% concentration

Steam Cleaning:

6. **Steam Wash** - 1 to 5% concentration depending on soil load

DIRECTIONS FOR MIXING

| % Concentration | Amount of BC 4000 | Amount of Water (Gallons) |
|-----------------|-------------------|---------------------------|
| 1 | 1 qt. | 25 |
| 2 | 1 qt. | 12 1/2 |
| 3 | 1 qt. | 9 3/8 |
| 4 | 1 qt. | 6 1/4 |
| 5 | 1 qt. | 5 |
| 6 | 1 qt. | 4 1/8 |
| 7 | 1 qt. | 3 2/3 |
| 8 | 1 qt. | 3 1/8 |
| 9 | 1 qt. | 2 3/4 |
| 10 | 1 qt. | 2 1/2 |

STORAGE AND HANDLING

Store in a cool dry area. This product is freeze thaw stable and should it freeze, let it thaw at room temperature and mix contents before use.

BC 4000 contains no caustic, but it is alkaline. Therefore, gloves and goggles should be worn while handling the concentrate and ready to use solution.

FOR INDUSTRIAL USE ONLY. KEEP OUT OF REACH OF CHILDREN

PRODUCT ORDERING INFORMATION:

| Product Number | Size | Wt./Case | Case Quantity |
|----------------|----------|----------|---------------|
| BC 4000 | 1 Gallon | 38 | 4 |