

## BC-7000 Heavy Duty Aluminum Cleaner & Etch

### BC 7000

#### DESCRIPTION

BC 7000 is a super heavy duty cleaner for the heaviest cleaning job. In dilute form, it can also be used to etch aluminum prior to priming or painting.

#### KEY FEATURES

- **Good Cleaning** - effectively removes heavy soils
- **Aluminum Etch** - when used 12 ounces cleaner to 1 gallon of water.
- **Liquid Form** - for ease of handling, measuring and mixing.
- **Highly Concentrated** - for economical use. Available in quarts, gallons, 5 gallons, 55 gallon drums.

#### GENERAL PURPOSE

1. For heavy cleaning, dilute 1 part BC 7000 with 5 parts water. Apply to surface with pressure sprayer. Rinse with clean water
2. For aluminum etch, use 12 oz. BC 7000 to 1 gallon of water. Rinse with clean water.

#### HOW TO USE

Mix BC 7000 with cool water. Because of the alkaline nature of BC 7000, we recommend protective clothing, rubber gloves and face shield when using BC 7000.

#### STORAGE AND HANDLING

Store in a cool dry area. This product is freeze thaw stable and should it freeze, let it thaw at room temperature and mix contents before use.

FOR INDUSTRIAL USE ONLY. KEEP OUT OF REACH OF CHILDREN.

#### PRODUCT ORDERING INFORMATION:

Product Number	Size	Wt./Case	Case Quantity
BC 7000	1 Gallon	38	4