

Silver Bullet AM™ Clear Epoxy Coating

WE DO NOT RECOMMEND THE USE OF SILVER BULLET AM IN EXTERIOR APPLICATIONS

20-451AM CLEAR

DESCRIPTION	2 to 1 mix Water Base Epoxy protected with Agion® Silver Antimicrobial Type AC
USES	A tough, heavy duty, extremely chemical resistant epoxy designed for maximum performance in severe environments. It contains a compound to protect the coating against bacteria, mold, mildew, fungi and algae.
APPEARANCE	Gloss Clear
RECOMMENDED PRIMERS	Prime Solution 5250 / 5253 Primer

PHYSICAL PROPERTIES

WEIGHT PER GALLON	8.85 lbs.	
SOLIDS BY WEIGHT	39%	
SOLIDS BY VOLUME	34.5%	
RECOMMENDED DFT (per coat)	1.0 mils	
INDUCTION TIME	None	
WET FILM TO ACHIEVE DFT (unthinned Material)	3 mils	
THEORETICAL COVERAGE @ 1 Mil DFT	550 sq. ft./gallon	
PRACTICAL COVERAGE @ RECOMMENDED DFT	550 sq. ft./gallon	
DRY TIMES @ 70°F - 80°F (21° - 27°C) AND 50% RH	Tack Free	20-60 minutes
	Handle	2-4 hours
	Recoat	1 hour after dry to touch
	Fully Cured	7 days (rate can be accelerated)
POT LIFE	4 hours with no reduction of gloss (subject to temperature and humidity conditions)	
DRY HEAT RESISTANCE	300° F	
SHELF LIFE	1 year (single component - not mixed)	
PACKAGING	1 gallon, 5 gallon	

SURFACE PREPARATION

All Surfaces: Surface prep is one of the most important steps for a successful paint job. If the surface is not adequately cleaned, then a future paint failure could occur. Remove all grease, oils, salts and other contaminants by washing with Burke BC4000 cleaner thinned from 5 parts water to 1 part cleaner up to 9 parts water to 1 part water. More contaminants require a stronger mix. Spray the cleaner on and wipe with clean rags. If you notice any cratering or crawling of the coating on application, STOP and rewash entire surface. Extremely smooth or slick metal may require scuff sanding for maximum adhesion.

APPLICATION Apply only when air and surface temperatures are between 50°F and 100°F and surface temperature is at least 5°F above the dew point.

THINNING

ROLLER/BRUSH Use as mixed. Thin with water as needed.
AIR-ATOMIZED SPRAY Thin 10% with water if needed.
AIRLESS SPRAY Normally not needed.
CLEANUP Soap and water.

EQUIPMENT RECOMMENDATIONS

BRUSH Quality synthetic bristle brush
ROLLER Use good quality roller cover.
AIR ATOMIZED SPRAY Follow equipment manufacturer's nozzle and needle selection recommendation for use with medium viscosity paints. Spray at a starting pressure of 45-60 PSI (adjust pressure and fluid as needed) For maximum yield: use a Binks 63ss tip with a .028 (0.7mm) orifice (12 oz. flow rate)
AIRLESS SPRAY 1800 - 2400 psi with a .013to .015 tip.
HOT SPRAY 120 F

SAFETY INFORMATION

VOC 171g/l or 1.45 # per gallon
FLASH POINT N/A

WARNING California Prop. 65 warning: Detectable amounts of chemicals known to the state of California to cause cancer, birth defects or other reproductive harm, may be found in this product or its vapors.

For specific information refer to the Material Safety Data Sheet.

FOR INDUSTRIAL USE ONLY. KEEP OUT OF REACH OF CHILDREN

PRODUCT ORDERING INFORMATION:

Product Number	Size	Wt./Case	Case Quantity
20-451AMHVAC-F1	1 Gallon	37	4
20-451AMHVAC-F5	5 Gallon	48	1